



DAYLIGHT HARVESTING SENSOR

0-10V • LOW VOLTAGE • CEILING MOUNT

INSTALLATION & OPERATION INSTRUCTIONS

(Units w/ Date Code 201214 and later)

CATALOG NUMBERS	DESCRIPTIONS
OCS-250-1-D	DAYLIGHT HARVESTING SENSOR 0-10V, LOW VOLTAGE, CEILING MOUNT

ADDITIONAL OPTIONS

- **HE:** High Humidity Environment

OVERVIEW

Cadence daylight harvesting sensors measure a spaces overall illumination in order to dim connected lighting for energy savings. During times of high daylight contribution to a space, controlled artificial lighting will be gradually dimmed to an energy saving level. During times of no or low daylight contribution, controlled artificial lighting will increase back up to its maximum level. The sensor can also be configured to signal a connected power pack to switch lighting off completely in maintained high daylight conditions. Additional configurable parameters include high & low trim levels and fade rates.

SPECIFICATIONS

ELECTRICAL

OPERATING VOLTAGE

12-24 VAC/VDC

CURRENT DRAW

2mA

DIMMING CAPACITY

50mA

DIMMING COMPATIBILITY

0-10 VDC Ballasts or Drivers
Compliant with IEC 60929
Annex E.2

PHYSICAL

SIZE

4.00" Diameter x 1.25" H
(10.16 x 3.17 cm)

WEIGHT

4.75 oz

COLOR

White

ENVIRONMENTAL

OPERATING TEMP

32°F to 122°F (0°C to 50°C) - Standard
-40° F/C (with **-HE** Option)

RELATIVE HUMIDITY

0-95% Non-Condensing,
Indoor Use Only

OPERATIONAL MODES

Daylight Harvesting to Low Trim

Daylight Harvesting to Off
(requires power pack)

CODE COMPLIANCE

Sensors can be used to meet
ASHRAE 90.1, IECC, & Title 24
energy code requirements

FEATURES

- Auto-Setpoint Selection Mode
- Adjustable High & Low Trim Level
- Works Along Side Low Voltage Occupancy Sensors
- Compact Size and Matte Finish
- Four Contractor Friendly Mounting Methods
- Mounting Nipple Attachment with Integrated Hole Saw




DAYLIGHT SENSOR PLACEMENT

Typically, a daylight harvesting sensor should be located in the intermost area of a daylighting zone. This assures that the setpoint is maintained at a minimum across the entire daylight zone. Additionally, the lights being controlled should be visible from the sensor as this will improve the tracking accuracy. This is referred to as close loop operation. Using the sensor where it is not able to monitor the lights it is controlling (i.e. open loop operation) will result in lights being either at full bright level or full dim level, but no levels in between. Placement directly above indirect lighting fixtures is not recommended.


INSTALLATION INSTRUCTIONS

MOUNTING OPTIONS

- Chase nipple & lock nut (included) for mounting unit to ceiling tile or 1/2" knockout in junction box. See Side Diagram below.
- Screw holes for directly mounting to ceiling surface, 3-1/2" (trade size) octagon box, or mud ring with 2-3/4" spaced ears. See Front Diagram below.




SIDE




Note: If mounting to a Single Gang Mudring, Handy Box, or 4" Octagon Box, a trim ring is required. Part Number: **OCS-299-JP**.

WIRING

STANDARD WIRING




STANDALONE DAYLIGHT HARVESTING APPLICATION



WIRING (CONT.)

DAYLIGHT HARVESTING + OCCUPANCY SENSORS APPLICATION



CONFIGURATION SETTINGS

PHOTOCELL SETPOINT

The minimum overall light level that is to be maintained in a space by the sensor is referred to as the "setpoint". This value is user selectable or can be chosen by the Auto-Setpoint function that is built into the sensor.

SETPOINT CONFIGURATION

1. Read through the below setpoint values list and note the number of the desired setpoint (e.g., default is 7 = 25 fc).
2. Press and release the unit's pushbutton 4 times, then wait 2 seconds. The white LED will blink back the number of the current setting.*
3. At any time after blinking starts, enter number of new setting (from Setpoint Value Table).
4. New setting is saved after white LED blinks new setting back 3 times. If blue LED double flashes at any time, an error condition exists and process must be repeated.

FUNCTION #4 - SETPOINT VALUE TABLE

SETTING #	DESCRIPTION
2	Run Auto-Setpoint*
3	2.5 fc
4	5.0 fc
5	10.0 fc
6	15.0 fc
7	25 fc (default)
8	35 fc
9	50 fc
10	75 fc
11	100 fc

Manual Setpoint Options

*If Auto-Setpoint has been previously run, the value will be blinked back in two alternating digits:
Blue LED = 10's digit (1-9 blinks or rapid blink or 0)
White LED = 1's digit (1-9 blinks or rapid blink or 0)

*AUTO-SETPOINT SELECTION DETAILS

- A Once setting 2 "Run Auto-Setpoint" has been selected (by following above steps 1-4), the sensor's LED will alternate blue and white for 30 seconds. During this time user should move away from sensor.
- B Lights will then be cycled in order for sensor to calculate the controlled (artificial) light level. This is done by subtracting the light level with the lights off (relay open) from the light level with the lights on (relay closed).
- C A setpoint will then be chosen using the following conditions:
 - If controlled level is less than 3 fc, the application is considered open loop and the setpoint will be set to 50% of the measured level with the relay closed (plus a margin to prevent cycling). Setting will be between 0.5 fc and 44 fc.
 - If controlled level is between 3 and 50 fc, setpoint will be set to that level times 1.25.
 - If controlled level is greater than 50 fc the setpoint will be set to 50 fc.
- D Unit will immediately start operating with new setpoint (i.e. blue LED may begin flashing indicating it will transition lights soon)
- E To check auto selected setpoint, press and release button 4 times. Setpoint will be blinked back in two alternating digits:
Blue LED = 10's digit (1-9 blinks or rapid blink or 0)
White LED = 1's digit (1-9 blinks or rapid blink or 0)

CONFIGURATION SETTINGS (CONT.)

DAYLIGHT HARVESTING TURN OFF MODE

The daylight harvesting sensor measures the ambient light level and adjusts its 0-10V output between the high and low trim levels in order to maintain the photocell setpoint. Once the output reaches the low trim level, operation follows one of the three configurable **TURN OFF MODE** settings (see table on right).

CHANGING THE TURN-OFF MODE

1. Read through the **FUNCTION #5 - TURN OFF MODE** table and note the SETTING # of the desired mode.
2. Press and release the unit's pushbutton 5 times, then wait 2 seconds. The white LED will blink back the number of the current setting (e.g. 5 for **FADE TO LOW TRIM**).
3. At any time after blinking starts, enter number of new setting (e.g., 4 for **FADE TO OV**).
4. New setting is saved after white LED blinks new setting back 3 times. If blue LED double flashes at any time, an error condition exists and process must be repeated

FUNCTION #5 TURN OFF MODE

SETTING #	VALUES	NOTES
2	Drop to Off	Dimming output drops to low trim level & connected power pack's relay is signaled to open (i.e. blue wire goes low).
3	Fade to Off	Dimming output fades to low trim and connected power pack's relay is signaled to open (i.e. blue wire goes low).
4	Fade to OV	Dimming output fades to low trim level and then drops to 0 volts (e.g. below a connected driver's electronic off level). The connected power packs's relay is signaled to remain closed (i.e. blue wire stays high).
5	Fade to Low Trim (default)	Dimming output fades down to low trim level and the connected power packs's relay is signaled to remain closed (i.e. blue wire stays high).
6	Drop to Low Trim	Dimming output drops down to low trim level and the connected power packs's relay is signaled to remain closed (i.e. blue wire stays high).
7	Drop to OV	Dimming output drops to 0 volts (e.g. below a connected driver's electronic off level and the connected power packs's relay is signaled to remain closed (i.e. blue wire stays high).

LED INDICATION

Prior to the daylight harvesting sensor turning lights on or off, the unit's LED will blink blue at 0.5 sec intervals to indicate a pending transition. The LED also blinks twice rapidly every 15 sec when lights are being held off during occupied periods of high ambient light. The intensity of this LED can be increased or disabled.

TO CHANGE LED INTENSITY SETTINGS:

1. Press unit's pushbutton 7 times, then wait two seconds. The white LED will blink back the number of current setting.
2. Change to new setting by pressing the button equal times to below numbered choices:
3. New setting will be saved after white LED blinks back number three times. If blue LED double flashes at any time, start process over.

FUNCTION #7 - LED INTENSITY

SETTING #	DESCRIPTION
2	Normal brightness [Default]
3	Increased brightness
4	Disable LED

RESET

To restore factory settings, press and release the pushbutton 8 times, wait 2 seconds, then press and release the pushbutton 3 times again.

CONFIGURATION SETTINGS (CONT.)

DETAILED DIMMING CONFIGURATION

Several dimming parameters can be adjusted using the following programming procedure.

- 1 From the below tables of detailed dimming functions, note the number (#) of the function to be modified. For example, the HIGH TRIM setting is #9.
- 3 To access a particular function, press and release the programming button the number of time of the chosen function. For example, press the button 9 times to access the HIGH TRIM function.
- 4 The LED will flash back the setting number of the current value as it appears in each function's detailed table below. For example, the default HIGH TRIM is setting #2 (10V)
- 5 To change the setting number, press and release the button the number of times equal to the new setting #. For example, 3 times (for 9V).
- 6 The LED will flash back the new setting number as confirmation and will be saved after three confirmations. If blue LED double flashes at any time, start process over.

DETAILED DIMMING FUNCTION TABLES

FUNCTION #9 HIGH TRIM

The maximum voltage to which the daylight harvesting sensor is allowed to raise its dimming output when measuring a low level of ambient light.

SETTING #	VALUES	NOTES
2	10 VDC (default)	Light output at each voltage level depends on driver/ballast and luminaire.
3	9 VDC	
4	8 VDC	
5	7 VDC	
6	6 VDC	
7	5 VDC	

FUNCTION #10 LOW TRIM

The minimum voltage to which the daylight harvesting sensor is allowed to reduce its dimming output when measuring high levels of ambient light.

SETTING #	VALUES	NOTES
2	0 VDC	Light output at each voltage level depends on driver/ballast and luminaire.
3	1 VDC	
4	2 VDC	
5	3 VDC (default)	
6	4 VDC	
7	5 VDC	
8	6 VDC	

FUNCTION #11 FADE OFF TIME

Adjustable time interval for lights to ramp down to off.

SETTING #	VALUES	NOTES
2	0.75 Sec	Default for all models
3	1.5 Sec	
4	3 Sec	
5	5 Sec	
6	15 Sec	

FUNCTION #12 FADE ON TIME

Time interval for lights to ramp up when connected occupancy sensors signal an occupied state.

SETTING #	VALUES	NOTES
2	0.75 Sec	Default for all models
3	1.5 Sec	
4	3 Sec	
5	5 Sec	
6	15 Sec	